
CONSTRUCTION ENGINEERING RESEARCH LAB (ARMY) CHAMPAI--ETC F/G 5/1
SUPERVISION AND ADMINISTRATION COST/RATE FORECASTING SYSTEM. VO--ETC(U)
MAR 78 M J O'CONNOR, R LIDRAL
CERL-SR-P-87 NL AD-A053 229 UNCLASSIFIED · loFl QD A053229 END DATE FILMED 6= 78



construction engineering research laboratory

SPECIAL REPORT P-87 March 1978

SUPERVISION AND ADMINISTRATION COST/RATE FORECASTING SYSTEM VOLUME I: USER'S MANUAL



ODG FILE COPY.

by Michael J. O'Connor Robert Lidral





The contents of this report are not to be used for advertising, publication, or promotional purposes. Citation of trade names does not constitute an official indorsement or approval of the use of such commercial products. The findings of this report are not to be construed as an official Department of the Army position, unless so designated by other authorized documents.

DESTROY THIS REPORT WHEN IT IS NO LONGER NEEDED
DO NOT RETURN IT TO THE ORIGINATOR

COMPUTER PROGRAM DATA SHEET

Title: Supervision and Administration (S&A) Cost/Rate Forecasting System.

Proponent: Directorate of Military Construction Data Processing Installation: Construction Division of MC Operations and Planning Branch

Language: BASIC

Hardware: Tektronix 4051

Availability: Corps of Engineers Engineering Computer Programs Library.

N. H

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE	READ INSTRUCTIONS BEFORE COMPLETING FORM			
1. REPORT NUMBER 2. GOVT ACCESSION NO. SPECIAL REPORT P-87	3. RECIPIENT'S CATALOG NUMBER			
SUPERVISION AND ADMINISTRATION COST/RATE FORE- 9	SPECIAL rept.			
VOLUME I USER'S MANUAL.	6. PERFORMING ORG. REPORT NUMBER			
Michael J./0'Connor 14 CERLI-SR-Robert/Lidral	P-87			
9. PERFORMING ORGANIZATION NAME AND ADDRESS CONSTRUCTION ENGINEERING RESERACH LABORATORY P.O. Box 4005 Champaign II 61820	10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS			
Champaign, IL 61820	(MCC 77-1)			
11	Mar Mar 18 78 19 19 19 19 19 19 19 19 19 19 19 19 19			
14. MONITORING AGENCY NAME & ADDRESS(II different from Controlling Office)	15. SECURITY CLASS. (of this report)			
	Unclassified 15a. DECLASSIFICATION/DOWNGRADING SCHEDULE			
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)				
18. BUPPLEMENTARY NOTES				
Copies are obtainable from National Technical Information Service Springfield, VA 22151				
19. KEY WORDS (Continue on reverse elde II necessary and Identify by block number) supervision and administration Corps of Engineers military construction				
This volume describes the use of the Supervision and Administration (S&A) Cost/Rate Forecasting System to maintain S&A data, to update the S&A forecasting model, and to forecast future S&A costs and rates. Volume II, the Programmer's Guide, contains software documentation.				

FOREWORD

This research was conducted for the Directorate of Military Construction, Office of the Chief of Engineers (OCE), under O&MA FAD No. 7635-1 (MCC 77-1) dated 1 October 1976. The OCE Technical Monitor was Mr. David A. Spivey.

The work was performed by the Facility Systems Division (FS), U.S. Army Construction Engineering Research Laboratory (CERL), Champaign, IL. The Principal Investigator was Mr. Michael J. O'Connor. Mr. E. A. Lotz is Chief of FS.

COL J. E. Hays is Commander and Director of CERL, and Dr. L. R. Shaffer is Technical Director.

ACCESSION for		
NTIS	White Section	
DDC	Buff Section	
UNANNOUNCED	ō	
JUSTIFICATION		
BY		
	VARLABILITY CÓDES	
DISTRIBUTION/A	VALABILITY CODES and/or SPECIAL	

CONTENTS

		Page
	DD FORM 1473 FOREWORD LIST OF FIGURES	1 3 5
1	INTRODUCTION Background Objective Approach	6
2	GENERAL SYSTEM USE	7
3	COMMANDSAdd a Division/District Database Delete a Division/District Database Change a Division/District Database Display a Division/District Database Perform Regression Analysis Display Model Equation and Statistics Plot S&A Cost/Rate Curves Forecast S&A Cost/Rate	8
	DISTRIBUTION	

FIGURES

Number		Page
1	System Menu Display	7
2	Add a Division/District Database Command	9
3	Delete a Division/District Database Command	9
4	Change a Division/District Database Command	10
5	Display a Division/District Database Command	12
6	Sample Database Display	12
7	Display Model Equation and Statistics Command	13
8	Sample Model Equation and Statistics Display	13
9	Plot S&A Cost/Rate Curves Command	14
10	Sample Plot of S&A Cost/Rate Curves	15
11	Forecast S&A Cost/Rate Command	16

SUPERVISION AND ADMINISTRATION COST/RATE FORECASTING SYSTEM VOLUME I: USER'S MANUAL

1 INTRODUCTION

Background

A statistical model for forecasting Supervision and Administration (S&A) costs/rates has been developed to aid the Directorate of Military Construction (DMC), Office of the Chief of Engineers (OCE), in establishing S&A limits for each military construction Division and District. The S&A Cost/Rate Forecasting System is a computer program which provides the DMC with the capability to maintain, update, and use the S&A forecasting model. The system maintains and updates work placement and S&A cost data for each military construction Division and District for the period of 12 fiscal years. It performs multiple linear regression analyses on these data to update the statistical models for predicting S&A costs and rates and 95 percent prediction limits for each Division/District.

The S&A Cost/Rate Forecasting System is implemented on a Tektronix 4051 in BASIC. Programs and data reside on tape casettes.

Objective

The objective of Volume I of this report is to describe and provide user instructions for the S&A Cost/Rate Forecasting System. Volume II contains software documentation.

<u>Approach</u>

Chapter 2 provides general instructions for system use and Chapter 3 describes system commands.

O'Connor, M. J., and Thompson, B., Military Construction Supervision and Administration Cost Forecasts, Technical Report P-80/ADA040742 (U.S. Army Construction Engineering Research Laboratory [CERL], May 1977).

2 GENERAL SYSTEM USE

The S&A cost/rate forecasting system is loaded by inserting the tape casette on which it resides into the Tektronix 4051 and pressing AUTO LOAD. Once loaded, the program displays the system menu and prompts the user for further input, as illustrated in Figure 1. For example, if the user wishes to display the data for Alaska, he or she should respond by typing "4,1". The execution of any command causes the menu to be cleared from the screen and appropriate command information to be displayed. Each command display includes the description of the command that is being executed and the name of the database upon which it is operating. Prompts for additional user action and the output from the command are displayed as appropriate. Completion of each command is indicated by the prompt for a new command. Upon detection of an error, an error message is displayed and the processing of the command or subcommand is terminated. Should an error occur which is not handled by the system and, thus, aborts the program, recovery may be easily accomplished by pressing AUTO LOAD; results of previous, successful commands will still be valid.

SUPERVISION AND ADMINISTRATION COST/RATE FORECASTING SYSTEM

COMMANDS DESCRIPTION ID ADD A DIVISION/DISTRICT DATABASE DELETE A DIVISION/DISTRICT DATABASE CHANGE A DIVISION/DISTRICT DATABASE DISPLAY A DIVISION/DISTRICT DATABASE 5 PERFORM REGRESSION ANALYSIS DISPLAY MODEL EQUATION AND STATISTICS PLOT S&A COST/RATE CURVES FORECAST SAA COST/RATE DATABASES ID NAME ID NAME ALASKA BALTIMORE KANSAS CITY FORT WORTH LOS ANGELES 6 MEDITERRANEAN MOBILE 8 **NEW YORK** NORFOLK 10 AHAMO PACIFIC OCEAN **SACRAMENTO** SAVANNAH ENTER "<COMMAND ID>, <DATABASE ID>" OR "M" FOR MENU OR "Q" TO QUIT

Figure 1. System menu display.

3 COMMANDS

Add a Division/District Database

This command is used to add an entirely new database to the system. The new database ID must not be the same as the ID of any existing database and must be a positive integer between 1 and 99, inclusive; the database name also must not be the same as that of any existing database. The system will prompt the user for the database name and data as illustrated in Figure 2. A database name may be any alphanumeric string up to 20 characters long.

Delete a Division/District Database

This command deletes the entire 12-record database for the specified Division/District. To prevent accidental deletions, this command prompts the user to verify that he or she really wishes to delete the dataset. See Figure 3 for an example of this command.

Change a Division/District Database

This command is used to change data records and to add the newest (or oldest) and delete the oldest (or newest) record in the existing database. The system issues the following prompt:

ENTER "<FY>, <WORK PLACEMENT>, <S&A COST>"

The fiscal year must be a two-digit number equal to either (1) one of the years in the existing database, (2) one year earlier than the earliest year, or (3) one year later than the latest existing year. The work placement and S&A cost are decimal numbers that express the costs in millions of dollars. If the fiscal year entered by the user matches the fiscal year of an existing data record, then that record's data will be replaced with the new input data after the user is prompted for verification. If the fiscal year is one greater than the most recent or one less than the least recent, then the whole database is shifted one year to accommodate the new data, deleting the record at the opposite end of the database (in either case, the user is informed of the deletion). If all three values are zero, the command terminates. Upon successful completion of a change transaction (other than one with three zeroes), the change prompt is reissued. Changes to a Division/District database will "zero out" the previously existing forecasting model for that Division/District to insure that all forecasts are based on the current database. See Figure 4 for an example of the use of this command.

ADD A DIVISION/DISTRICT DATABASE

DATABASE ID = 1

ENTER " <DATABASE NAME>" >ALASKA

DATA FOR 12 CONSECUTIVE YEARS MUST BE ENTERED IN ASCENDING ORDER (2 DIGIT FY, COST IN MILLIONS)
ENTER RECORD 1: "<FY>, <ESTIMATED WORK PLACEMENT>, <S&A COST>"
>65, 27.323, 1.707
ENTER RECORD 2 FOR FY66: "<ESTIMATED WORK PLACEMENT>, <S&A COST>"
>20.477, 1.701

ENTER RECORD 12 FOR FY76: "<ESTIMATED WORK PLACEMENT>, S&A COSTS>" >38.287, 2.336

ENTER "<COMMAND ID>, <DATABASE ID>"
OR "M" FOR MENU OR "Q" TO QUIT

Figure 2. Add a Division/District database command.

DELETE A DIVISION/DISTRICT DATABASE

DATABASE 1 FOR DIVISION/DISTRICT ALASKA
TYPE "YES" TO DELETE, ANYTHING ELSE TO LEAVE AS IS
>YES
DATABASE 1 FOR DIVISION/DISTRICT ALASKA DELETED

ENTER " <COMMAND ID >, < DATABASE ID >'
OR "M" FOR MENU OR "Q" TO QUIT
>

Figure 3. Delete a Division/District database command.

CHANGE A DIVISION/DISTRICT DATABASE CHANGE DATABASE 1 FOR DIVISION/DISTRICT ALASKA

ENTER DATABASE CHANGES; TO TERMINATE, ENTER THREE ZEROES ENTER "<FY>,<WORK PLACEMENT>,<S&A COST>"
>64, 24.3, 1.6
ADDING YEAR TO BEGINNING OF DATA; LAST YEAR DISCARDED ENTER "<FY > <WORK PLACEMENT>, S&A COST "
>68, 21.731, 1.636
CHANGING DATA FOR FY68
DO YOU WISH TO CHANGE THIS DATA (YES OR NO)?
YES
ENTER "<FY>, <WORK PLACEMENT>, <S&A COST>"
>76, 38.287, 2.336
ADDING YEAR AT END OF DATA; FIRST YEAR DISCARDED ENTER "<FY>, <WORK PLACEMENT>, <S&A COST>"
>0, 0, 0

ENTER "<COMMAND ID>, <DATABASE ID>"
OR "M" FOR MENU OR "Q" TO QUIT

Figure 4. Change a Division/District database command.

Display a Division/District Database

This command displays the database for a specified Division/District, either on the graphic screen or on a hardcopy device at the user's option. Figure 5 demonstrates the use of this command, and Figure 6 shows a sample display.

Perform Regression Analysis

This command performs multiple linear regressions and statistical analysis necessary to determine the forecasting model for the specified Division/District database. There are no further user prompts for this command.

Display Model Equation and Statistics

This command displays the forecasting model and statistics for the specified Division/District, either on the graphic screen or on a hard-copy device at the user's option. Figure 7 demonstrates the use of this command, and Figure 8 shows a sample display.

Plot S&A Cost/Rate Curves

This command plots the S&A cost and S&A rate predictions vs. estimated work placement for the next fiscal year for the specified Division/District. Output is displayed on either the graphic screen or the digital plotter at the user's option. If a plot over the entire allowable range for estimated work placement is not desired, a subrange may be specified. Figure 9 shows an example of the use of this command, and Figure 10 shows a sample plot made by the digital plotter.

Forecast S&A Cost/Rate

This command calculates and displays the predicted S&A cost and rate for the next fiscal year and as a function of the estimated work placement for the specified Division/District. The system prompts the user for the estimated work placement and displays the forecasts as shown in Figure 11. A zero estimated work placement value will terminate the command.

DISPLAY A DIVISION/DISTRICT DATABASE

DATABASE 1 FOR DIVISION/DISTRICT ALASKA

WHICH DEVICE "SCREEN" OR "HARDCOPY"? >HARDCOPY

ENTER " <COMMAND ID>, < DATABASE ID>"
OR "M" FOR MENU OR "Q" TO QUIT

Figure 5. Display a Division/District database command.

DISPLAY A DIVISION/DISTRICT ALASKA

<u>FY</u>	WORK PLACEMENT (MILLION \$)	S&A COST (MILLION \$)	S&A RATE(%)
65	27.323	1.707	6.25
66	20.477	1.701	8.31
67	18.547	1.686	9.09
68	21.731	1.636	7.53
69	31.620	2.268	7.17
70	27.356	1.794	6.56
	15.527	1.121	7.22
71 72	18.567	1.458	7.85
73	18.609	1.519	8.16
74	29.411	1.789	6.08
75	27.040	2.178	8.05
76	38.287	2.336	6.10

Figure 6. Sample database display.

DISPLAY MODEL FUNCTION AND STATISTICS

WHICH DEVICE "SCREEN" OR "HARDCOPY"? > HARDCOPY

ENTER "<COMMAND ID>, <DATABASE ID>"
OR "M" FOR MENU OR "Q" TO QUIT

Figure 7. Display model equation and statistics command.

DISPLAY MODEL EQUATIONS AND STATISTICS ALASKA

FY65 THRU FY76 DATA

S&A COST = 0.647 + 0.0456W 0.000T 0.00000WT

STANDARD ERROR OF THE ESTIMATE: S = 0.178
COEFFICIENT OF DETERMINATION: R**2 = 0.765

S&A COST IN MILLIONS OF DOLLARS
W = ESTIMATED WORK PLACEMENT IN MILLIONS OF DOLLARS
T = TIME, WHERE FY76 = 12, FY77 = 13

Figure 8. Sample model equation and statistics display.

PLOT S&A COST/RATE CURYES

ENTER DEVICE: "1" FOR GRAPHIC SCREEN, "2" FOR DIGITAL PLOTTER >2
ENTER WORK PLACEMENT RANGE: "<MINIMUM>,<MAXIMUM>" OR CR > (return)

TO PLOT GRAPH, PRESS RETURN
WHEN THE GRAPH IS FINISHED, PRESS
RETURN AGAIN TO CLEAR THE SCREEN
(return)
(return)

ENTER "<COMMAND ID>, <DATABASE ID>"
OR "M" FOR MENU OR "Q" TO QUIT

Figure 9. Plot S&A cost/rate curves command.

8 AND A COST/RATE VS ESTIMATED WORK PLACEMENT ALASKA - FY77 PREDICTED VALUE --- 95X PREDICTION LIMITS




Figure 10. Sample plot of S&A cost/rate curves.

FORECAST S&A COST/RATE ALASKA FY77

ENTER " ESTIMATED WORK PLACEMENT>" (MILLION \$: "0" TO QUIT >40

S&A COST = 2.50 ± 0.60 MILLION DOLLARS (95% PREDICTION LIMITS) S&A RATE = 6.21 ± 1.59 PERCENT (95% PREDICTION LIMITS)

ENTER "<ESTIMATED WORK PLACEMENT>" (MILLION \$ = "0" TO QUIT)

ENTER "<COMMAND ID>, <DATABASE ID>"
OR "M" FOR MENU OR "Q" TO QUIT

Figure 11. Forecast S&A cost/rate command.

CERL DISTRIBUTION

Chief of Engineers
ATTN: DAEN-ASI-L (2)
ATTN: DAEN-MCZ-S
ATTN: DAEN-RDL
ATTN: DAEN-MCC-C/D. Spivey (20)
Dept of the Army
WASH DC 20314

Defense Documentation Center ATTN: TCA (12) Cameron Station Alexandria, VA 22314 O'Connor, Michael J

Supervision and administration cost/rate forecasting system / by Michael J. O'Connor, Robert Lidral. - Champaign, IL.: Construction Engineering Research Laboratory; Springfield, Va.: available from National Technical Information Service, 1978.

v. : ill. ; 27 cm. (Special report - Construction Engineering Research Laboratory ; P-87)

1. U.S. Army - military construction operations. I. Lidral, Robert. II. Title. III. Series: U.S. Construction Engineering Research Laboratory. Special report; P-87.